

## Interchange Table for DELTA VU Pumps

Brand	Type	Interchange Type
DELTA	VM1-LL1	VU1
	VM1-LR1	VU1
	VM1-LL2	VU1
	VM1-LR2	VU1
	VM1-RL1	VU1
	VM1-RR1	VU1
	VM1-RL2	VU1
	VM1-RR2	VU1
	VM2-LL1	VU2
	VM2-LR1	VU2
	VM2-LL2	VU2
	VM2-LR2	VU2
	VM2-RL1	VU2
	VM2-RR1	VU2
	VM2-RL2	VU2
	VM2-RR2	VU2
	DANFOSS	BFP 21 L3
BFP 21 R3		VU1
BFP 21 L5		VU2
BFP 21 R5		VU2
SUNTEC	AL 35 A	VU1
	AL 35 B	VU1
	AL 35 C	VU1
	AL 35 D	VU1
	AL 55 A	VU2
	AL 55 B	VU2
	AL 55 C	VU2
	AL 55 D	VU2
	AS 47 A	VU1
	AS 47 B	VU1
	AS 47 C	VU1
	AS 47 D	VU1
	AS 57 A	VU2
	AS 57 B	VU2
	AS 57 C	VU2
	AS 57 D	VU2

errors excepted