


Part List



Nr.	DESCRIPTION	Nr.	DESCRIPTION
1	Pump housing	26	Shaft
2	Cover	27	Key
3	-	28	Shaft spring
4	Cover fixing screw	29	Brass cover
5	Joint plate	30	O-ring 2031
6	-	31	O-ring 18x3
7	Strainer	32	Circlip
8	Cover plate	33	Cast iron ring
9	Gear set	34	Carbon ring
10	Gear plate	35	Valve spring
11	Plate fixing screw	36	Magnetic core
12	1/4" plastic plug	37	O-ring 2021
13	-	38	Stem
14	By-pass plug	39	Coil fixing nut
15	Nozzle port	40	-
16	Piston	41	Coil
17	Pressure regulating spring	42	O-ring 114
18	Locking nut	43	G1/4" plug with by-pass housing
19	Pressure regulating plug	44	Adaptation flange
20	Pressure regulating screw	45	Flange fixing screw
21	Sliding plug	46	Bleeder plug
22	O-ring 2018	47	Bleeder screw
23	O-ring 108	48	O-ring 5x1
24	G1/8" plug	49	-
25	1/8" plastic plug	50	-