

## Burnerlance 32—H—BMS—"L"—"d"—H with internal heating

<u>Capnut</u> <u>Needle</u>

Adaptor Holder

Thermo-Coax

Triangle only for lances from 800 mm.

<u>"d"</u>

<u>SW. 41</u>

32-XF08-4G-E

"L"<1200: 24V- 60W 1200<="L"<2400: 42V-100W

